



## INSTRUCTIONS, WARRANTY AND WARNINGS GORILLA GOALS

### Instructions for Use

#### Setting up the Gorilla Goal

- Upon receipt of your Gorilla goal, please check all components are present (inflatable structure, ground anchors, sandbags, pump and instruction leaflet).
- Carry the bag to the site of use and remove the components.
- Unpack and separate all items from the carry bag and unfold the inflatable structure.
- Attach pump hose to the inflate position on the pump handle.
- Depress the moveable centre piece of the valve on the goal and ensure it is turned fully anti-clockwise.
- Attach the end of the pump hose to the valve on the goal structure.
- Inflate the structure until rigid, ensuring the net isn't caught on the net clips throughout inflation.
- Stand the inflated stanchion into the appropriate position then secure with ground pegs for soft surfaces or sand bags for hard surfaces.

#### Packing the Inflatable Gorilla Goal Away

- Reverse of previous steps, depressing and turning the valve centre piece fully clockwise and using the deflate option on the pump to remove residual air.
- Unroll the bag inlay and lay the deflated structure along the length of it, with the end furthest from the bag tucked into the small pocket.
- Firmly roll the structure back towards the bag.
- Once the goal is in the main bag compartment zip up the front, add back all of the other components then zip and velcro the top of the bag shut.

### General

- The Gorilla Goal is a portable, inflatable structure and is expected to stand without significant loss of pressure for up to 8 hrs of continuous use. It is not a permanent structure and should not be expected to remain inflated indefinitely.
- Ensure that the net does not become tangled in the net clips during inflation as this will stop the structure holding the correct shape.
- Always remove residual air after use with deflation option on pump.

### Warning

- It is the user's responsibility to undertake location specific risk assessments to assess any potential hazards, such as trips etc. and to ensure that the equipment provided is used to minimise any potential hazards. No responsibility will be accepted by Phoenix Sporting Goods Ltd for any injury arising from the use of this product.



## INSTRUCTIONS, WARRANTY AND WARNINGS GORILLA GOALS

**Gorilla Goals are guaranteed for 24 months from the date of purchase against faulty materials or workmanship. During this period they will be replaced free of charge provided that:**

- The product is returned to place of purchase with evidence of purchase in accordance with the claims procedure outlined below.
- The product has been purchased by the user and not via another third party nor used for hire purposes.
- The product has been used in accordance with instructions provided with product at time of purchase and not outside warranty guidance.
- The product must not have been misused or handled carelessly, or by ignoring the warnings included with the instructions.
- Repairs have not been attempted with anything other than product specific kit.
- Inflatable structures are only guaranteed for periods of use up to 8 hours.

### Claims Procedure

**Any claim made under this guarantee should be made directly to the place of purchase where the product was purchased. The claim itself should ideally be made in writing together with the date and place of purchase, and giving a brief explanation of the problem, and circumstances which have led to the claim.**

PLEASE NOTE that it is essential that the claim reaches the place of purchase within 14 days of the last day of this Guarantee. Late claims will not be considered. This Guarantee applies to all Gorilla Goals goods purchased from an authorised reseller of Phoenix Sporting Goods Ltd.

This Guarantee does not confer any rights other than those expressly set out above and does not cover any claims for consequential loss or damage. This Guarantee is offered as an extra benefit and does not affect your statutory rights as a consumer.

### Returns

Your statutory right to a 14 day return applies, providing product is returned in original packaging and in a fully re-saleable condition. If any signs of wear are visible then a full refund will NOT be given.

If product is found to be unsaleable due to neglect or misuse then no refund will be offered.

For enquiries please contact your re-seller or [sales@phoenixsportinggoods.com](mailto:sales@phoenixsportinggoods.com) (if purchased directly).